



SEIT 1968

**4 IN 1
ELECTRIC JUICER**

**INSTRUCTION
MANUAL**



SEIT 1968

Please retain instructions for future reference.

Safety Instructions

When using electrical appliances, basic safety precautions should always be followed.

Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.

Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance, only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should be supervised to ensure that they do not play with the appliance.

Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance.

This appliance is not a toy.

If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.

This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.

Keep the appliance and its power supply cord out of the reach of children.

Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.

Keep the appliance away from heat emitting appliances.

Keep hands, fingers, hair and any loose clothing away from the rotating tools of the appliance.

Do not touch any moving parts on this appliance during use, as this could cause injury.

Do not immerse the appliance in water or any other liquid.
Do not operate the appliance with wet hands.
Do not use broken or loose cutting or rotating blades.
Do not overload the appliance as the mixture level may rise during blending.
Do not leave the appliance unattended whilst connected to the mains power supply.
Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.
Do not use the appliance for anything other than its intended use.
Do not use any accessories other than those supplied.
Do not use this appliance outdoors.
Do not store the appliance in direct sunlight or in high humidity conditions.
Do not move the appliance whilst it is in use.
Do not place boiling water or very hot liquid in the appliance.
Always unplug the appliance after use and before any cleaning or user maintenance.
Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.
Use of an extension cord with the appliance is not recommended.
This appliance should not be operated by means of an external timer or separate remote control system, other than that supplied with this appliance.
This appliance is intended for domestic use only. It should not be used for commercial purposes.

WARNING: Do not touch sharp blades.



SEIT 1968

Care and Maintenance

Before attempting any cleaning or maintenance, switch off and unplug the juicer from the mains power supply and allow it to cool fully.

STEP 1: Wipe the juicer main unit with a soft, damp cloth and allow to dry thoroughly.

STEP 2: Wash all of the accessories in warm, soapy water, then rinse and dry thoroughly.

Never touch the chopping blades; using extreme caution, clean the blades with a brush and dry carefully.

Do not immerse the juicer main unit in water or any other liquid. Do not use harsh or abrasive detergents or scourers to clean the juicer, as this could cause damage.

NOTE: The juicer should be cleaned after each use.

WARNING: Handle the chopping attachments with care, as the blades are sharp. Exercise caution when attaching, removing, cleaning or storing attachments.

Description of Parts



1. 4 in 1 Electric Juicer main unit
2. Speed control dial
3. Pusher
4. Pulp collector
5. Juice collector
6. Lid cover
7. Filter
8. Anti-drip spout
9. Juice cup
10. Juice cup lid

11. Juice cup divider
12. Sports bottle
13. Sports bottle lid
14. Blender blade
15. Grinder cup
16. Grinder blade
17. 1 litre jug
18. 1 litre jug lid
19. Measuring cap



SEIT 1968

Instructions for Use

Before First Use

Wash all of the attachments in warm, soapy water, then rinse and dry thoroughly. Wipe the juicer main unit with a soft, damp cloth and allow to dry thoroughly.

NOTE: When using the juicer for the first time, a slight odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the juicer.

Assembling the 4 in 1 Electric Juicer

All attachments must be securely fitted before use; do not attempt to remove attachments until the blades have stopped moving.

STEP 1: Check that the juicer main unit is switched off and unplugged from the mains power supply.

STEP 2: Position the juicer main unit onto a flat, stable surface, at a height that is comfortable for the user. Check that the rubber feet are firmly planted so that the juicer does not wobble during use.

STEP 3: Make sure the speed control dial is set to position '0'.

STEP 4: Select the attachments as desired.

Assembling the Electric Juicer

STEP 1: Place the juice collector onto the juicer main unit. Align the locking tabs and gently press downwards. Twist in a clockwise direction until locked into place.

STEP 2: Place the filter inside the pulp collector and push downwards until it clicks.

STEP 3: Position the lid cover onto the juice collector and rotate in a clockwise direction until secure.

STEP 4: Lean the pulp collector under the lid cover.

Assembling the Blender with Sports Bottle

STEP 1: Place the ingredients to be blended into the sports bottle.

STEP 2: Carefully attach the blender blade by placing it on top of the sports bottle and rotating in a clockwise direction until locked into place.

STEP 3: Invert the sports bottle and place it on top of the juicer main unit. Align the blender blade locking tabs with the juicer main unit and gently press downwards. Twist in a clockwise direction until locked in place.

Assembling the Grinder Cup

STEP 1: Place the ingredients into the grinder cup.

STEP 2: Attach the grinder blade by placing it on top of the grinder cup and rotating in a clockwise direction until secure.

STEP 3: Carefully place the grinder blade onto the juicer main unit. Align the locking tabs and gently press downwards. Twist in a clockwise direction until locked into place.

Assembling the 1 Litre Jug

STEP 1: Carefully place the blender blade onto the juicer main unit. Align the locking tabs and gently press downwards. Twist in a clockwise direction until locked into place.

STEP 2: Position the 1 litre jug over the blender blade and rotate in a clockwise direction until secure.

STEP 3: Open the 1 litre jug lid by rotating it in an anticlockwise direction and lifting away from the 1 litre jug. Then add the food to be blended.

Using as a Juice Collector

STEP 1: Add food via the lid cover opening; the pusher can be used to push food into the juice collector chamber if necessary.

STEP 2: Plug in and switch on the juicer main unit at the mains power supply.

STEP 3: Holding the juicer main unit steady, rotate the speed control dial to the required setting.

STEP 4: Open the anti-drip spout and use the juice cup to collect any juice that is produced.

STEP 5: Additional food can be added through the lid cover opening using the pusher during juicing.

STEP 6: Turn the speed control dial back to position '0' after juicing is complete and wait until the blades stop rotating. Close the anti-drip spout.

STEP 7: Remove the lid cover by turning it in an anticlockwise direction and lifting it up away from the main unit.

STEP 8: Remove the pulp collector by lifting it up and away from the main unit. Carefully rotate the juice collector in an anticlockwise direction, while avoiding touching the blades on the filter, and detach it from the juicer main unit. Carefully remove and wash the filter.

NOTE: Setting '1' is recommended for soft foods and setting '2' for hard foods. Remove hard kernels from food before juicing. Cutting food into smaller pieces may improve results.

WARNING: Max. continuous operation time is 30 seconds. Leave to cool for at least 1 minute before using the juicer again.



SEIT 1968

Using as a Blender/Grinder

STEP 1: Prepare the food and fit the required attachments as desired.

STEP 2: Holding the juicer main unit steady, rotate the speed control dial to the required setting until the food is processed. Turn the control dial back to position '0' and wait for the blades to stop rotating before detaching the blender/grinder blade.

STEP 3: Remove the blender/grinder blade by twisting in an anticlockwise direction and lifting away from the juicer main unit.

NOTE: Use a small amount of liquid to help blend ingredients. Do not exceed the max. fill mark.

WARNING: Max. continuous operation time for grinding is 30 seconds. Leave to cool down for at least 10 minutes before grinding again.

Do not operate the blender whilst empty, as this can cause damage.

Do not blend warm or hot liquid or food.

Using the Speed Settings

Holding the juicer main unit steady, turn the speed control dial in a clockwise direction to select a speed setting or in an anticlockwise direction to activate the pulse setting (P).

The pulse setting provides quick bursts of speed. Hold the speed control dial in place to activate the motor and release to stop it.

Turn the speed control dial back to position '0' and wait for blades to stop rotating before removing attachments.

Storage

Check that the juicer main unit and its accessories are cool, clean and dry before storing in a cool, dry place.

Never wrap the cord tightly around the juicer; wrap it loosely to avoid causing damage.

Troubleshooting

Problem	Possible Cause	Solution
The juicer will not operate.	The juicer is not connected to the mains power supply. The juicer is not correctly assembled.	Plug in and switch on the juicer at the mains power supply. Check that the juicer has been correctly assembled and that the attachments are secure.
There are large unchopped chunks of ingredients after processing.	The juicer has been overfilled.	Remove some of the ingredients and chop in batches.
The sports bottle is leaking.	The sports bottle lid is not fitted correctly.	Checking that the threads are correctly aligned, twist the sports bottle lid in a clockwise direction until secure.

Specifications

Product code: PT4294

Input: 220-240 V~ 50-60 Hz

Output: 400 W



SEIT 1968

**UP Global Sourcing UK Ltd.,
Edmund-Rumpler Straße 5
51149 Köln, Germany.**

If this product does not reach you in an acceptable condition please contact our Customer Services Department at **customercare@upgs.com**

Please have your delivery note to hand as details from it will be required.

If you wish to return this product please return it to the retailer from where it was purchased with your receipt (subject to their terms and conditions).

Guarantee

All products purchased as new carry a manufacturer's guarantee; the time period of the guarantee will vary dependent upon the product. Where reasonable proof of purchase can be provided, Petra will provide a standard 12 month guarantee with the retailer from the date of purchase. This is only applicable when products have been used as instructed for their intended, domestic use. Any misuse or dismantling of products will invalidate any guarantee.

Under the guarantee, we undertake to repair or replace free of any charge any parts found to be defective. In the event that we cannot provide an exact replacement, a similar product will be offered or the cost refunded. Any damages from daily wear and tear are not covered by this guarantee, nor are consumables such as plugs, fuses etc.

Please note that the above terms and conditions may be updated from time to time and we therefore recommend that you check these each time you revisit the website.

Nothing in this guarantee or in the instructions relating to this product excludes, restricts or otherwise affects your statutory rights.

Disposal of Waste Batteries and Electrical and Electronic Equipment



This symbol on the product, its batteries or its packaging means that this product and any batteries it contains must not be disposed of with household waste. Instead, it is the user's responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. Some retailers provide take-back services which allow the user to return exhausted equipment for appropriate disposal. **It is the user's responsibility to delete any data on electrical and electronic equipment prior to disposal.** For more information about where to drop batteries, electrical and electronic waste off, please contact the local city/municipality office, household waste disposal service, or the retailer.

3 YEAR GUARANTEE

*To be eligible for the extended guarantee, go to **[guarantee.upgs.com/petra](https://www.guarantee.upgs.com/petra)** and register your product within 30 days of purchase.

Manufactured by:
UP Global Sourcing UK Ltd.,
Edmund-Rumpler Straße 5,
51149 Köln, Germany

MADE IN CHINA.

www.upgs.com/petra

©Petra Trademark. All rights reserved.



CD290920/MD180222/V2